ETCR2300/2300B Ground Pile Type Clamp Earth Resistance Tester





Product Function

Earth resistance measurement, loop resistance measurement, soil resistivity measurement, earth voltage measurement, grounding down lead leakage current and grounding fault judgement.

Product features

- 1. Use the clamp method, 2-wire method, 3-wire method, 4-wire method, selection method and other measurement methods to measure earth resistance.
- 2. Equip with 2.5-inch color LCD screen, and also with USB and charge port, with storage function, clock function, automatic storage the test results 500groups which containing the date and time.

2 Cunnert Android avetom	Bluetooth communication function,	ofter installing ADD as	in test or read test reserves in n	achila, bring nous ovnorioned
3. Support Anarola system	Bluetooth communication function.	aller mislammu APP Ca	in lest of read lest records in n	IODIIE. DI ITIQ TIEW EXDEFIEITCE.

Technica	Snocification
recifica	I Specification

ETCR®

Technical Specification			
Model	ETCR2300	ETCR2300B	
Earth Resistance Range	0.00Ω~20kΩ	0.00Ω~200kΩ	
Soil Resistivity Range	0.00Ωm~9999kΩm	0.00Ωm~9999kΩm	
Earth Current Range	0.000mA~20A	0.000mA~45A	
Earth Voltage Range	0.0V~600.0V	0.0V~600.0V	
Power Supply	DC 3.7V 2600mAh rechargeable lithium battery, full charge about 4.2V		
Display Mode	2.5 inch colorful LCD screen		
Earth Resistance	Clamp method, 2-wire method, 3-wire method, 4-wire method, selection method		
Test Frequency	128Hz/111Hz/105Hz/94Hz(AFC automatic frequency selection)		
Short-circuit Test Current	AC 10mA max		
Open-circuit Test Voltage	AC 14V max		
Electrode Spacing Range	1m~100m		
Clamp Jaw Size	65mmX32mm		
Tester Dimension	307mm(L)X98mm(W)X56mm(H)		
Tester Weight	Tester: about 1112g(include the battery); Total weight: about 5.1kg(include all accessories)		
Auxiliary Ground Rod	4 PCS: Φ9mmX230mm		
Test Line	4PCS: red 20m, black20m, yellow 10m, green 10m		
Simple Test Line	2PCS: red 1.6m, black 1.6m		
Measurement Times	Over 5000 times(short-circuit test, after one testing must stop 30s then can test again)		
Line Voltage	Measurement below AC 600V		
Data Storage	500groups		
Audible & Visual Alarm	"Du—du—du" alarm sound		
Automatic Shutdown	5 minutes without any operation after starting up, the detector will shutdown automatically		
Shift	Automatic		
External Magnetic & Electric Field	<40A/m; <1V/m		
Resistance Measurement Frequency	>1KHz, 128Hz		
Connection Interface	USB charge interface		
Accessories	Tester:1PC; Test ring: 1PCS; USB charge cable: 1PCS; Charger Adaptor: 1PCS; Ground stake: 4PCS; Test line: 4PCS; Simple test line: 2PCS; Tool bag: 1PCS		